































## Icon List

ZVI-SQTMDD

Application Program Version: [1.5]  
User Manual Version: [1.5]\_a

[www.zennio.com](http://www.zennio.com)

Icon	Name	Icon	Name
	Lamp off		Lamp on
	Lamp 2 off		Lamp 2 on
	Lamp 3 off		Lamp 3 on
	off 1		on 1
	AC Mode Auto		AC Mode Heat
	AC Mode Cool		AC Mode Fan
	AC Mode Dry		AC Split off
	AC Split on		AC Swing Move 1
	AC Swing Move 2		AC Swing Stop
	Accept		Cancel
	Clean Room 1		Clean Room 2
	Clean Room 3		Do not disturb
	Door close		Door open
	Door enter		Door exit

Icon	Name	Icon	Name
	Window close		Window open
	Key 1		Key 2
	Sound mute		Sound on
	Movie		Music
	Lock close		Lock open
	Fan min		Fan med
	Fan max		HVAC comfort
	HVAC standby		HVAC economy
	HVAC protection cool		HVAC protection heat
	Warning		Warning cold
	Warning fan		Warning hot
	Eco		No icon

Join and send us your inquiries  
about Zennio devices:  
<http://support.zennio.com>

**Zennio Avance y Tecnología S.L.**  
C/ Río Jarama, 132. Nave P-8.11  
45007 Toledo (Spain).

*Tel. +34 925 232 002*

*www.zennio.com*  
*info@zennio.com*



RoHS