





















# **INZENNIO Z38i**










## **List of Controls and Indicators**

# 1. INDIVIDUAL CONTROLS





















## BINARY

 (1) – Off	 (7) – Light Off	 (13) – Cancel
 (2) – On	 (8) –Light On	 (14) – Accept
 (3) – Off 2	 (9) –Light Off 2	 (19) – Off
 (4) – On 2	 (10) –Light On 2	 (20) – On
 (5) – Off 3	 (11) – Go out	 (21) – Unsecure
 (6) – On 3	 (12) – Go In	 (22) – Secure










## DIRECTIONAL & INCREMENTAL

 (25) – Down	 (31) – Left Arrow	 (37) – Minus
 (26) – Up	 (32) – Right Arrow	 (38) – Plus
 (27) – Left	 (33) – Down Shutter	 (39) – Down Temperature
 (28) – Right	 (34) – Up Shutter	 (40) – Up Temperature
 (29) – Down Arrow	 (35) – Down Shutter 2	
 (30) – Up Arrow	 (36) – Up Shutter 2	

















## AIR CONDITIONING

 (45) – Off A/C	 (52) – Lowest Fan	 (59) – Stop
 (46) – On A/C	 (53) – Low Fan	 (60) – Swing 2
 (47) – Cool Mode	 (54) – Middle Fan	 (61) – Automatic
 (48) – Heat Mode	 (55) – High Fan	 (62) – Automatic 2
 (49) – Auto Mode	 (56) – Highest Fan	 (63) – Automatic 3
 (50) – Fan Mode	 (57) – Stop (no swing)	 (64) – Automatic 4
 (51) – Dry Mode	 (58) – Swing	

















## NUMBERS

 (66) – Zero	 (71) – Five	 (76) – 0
 (67) – One	 (72) – Six	 (77) – 1
 (68) – Two	 (73) – Seven	
 (69) – Three	 (74) – Eight	
 (70) – Four	 (75) – Nine	

## SOUND & IMAGE



















 (78) – Stop	 (84) – Save	 (90) – Volume On
 (79) – Play	 (85) – Pause	 (91) – Television
 (80) – Rewind	 (86) – Eject	 (92) – Audio/Video
 (81) – Forward	 (87) –Volume Down	 (93) – Auxiliary
 (82) – Previous	 (88) –Volume Up	 (94) – Still
 (83) – Next	 (89) – Mute	 (95) – Movie

## OTHER

 (96) – Timer 1	 (102) – Set	 (108) – Very Strong
 (97) – Timer 2	 (103) – Ok	 (113) – Key 1
 (98) – Timer Off	 (104) – Comfort	 (114) – Key 2
 (99) – Timer On	 (105) – Economy	 (115) – New
 (100) – Make Up Room	 (106) – Standby	
 (101) – Do Not Disturb	 (107) – Strong	

## 2. DOUBLE CONTROLS











### BINARY

  (1) –Off / On	  (11) – Go Out/Go In
  (3) –Off / On 2	  (13) – Cancel/Accept
  (5) –Off / On 3	  (19) – Off/On
  (7) –Off / On Light	  (21) – Unsecure/Secure
  (9) –Off / On Light 2	


### DIRECTIONAL & INCREMENTAL


  (25) – Down/Up	  (33) – Down/Up Shutter
  (27) – Left/Right	  (35) – Down/Up Shutter 2
  (29) – Down/Up Arrow	  (37) – Minus/Plus
  (31) – Left/Right Arrow	  (39) – Down/Up Temperature

### AIR CONDITIONING


  (45) –Off/On A/C	  (57) – Stop/Swing
  (47) – Cool/Heat	  (59) – Stop/Swing 2
  (54) – Low/High Fan	


## NUMBERS

 (66) – Zero/One

 (72) – Six/Seven


 (68) – Two/Three

 (74) – Eight/Nine

 (70) – Four/Five


 (76) – 0/1


## SOUND & IMAGE

 (78) – Stop/Play

 (87) – Up/Down Volume


 (80) – Rewind/Forward

 (89) – Mute/Unmute

 (82) – Previous/Next

 (91) – TV/AV

## OTHER













 (98) – Timer Off/On

 (107) – Less/More Power


 (113) – Key 1/Key 2

### 3. INDICATORS











#### BINARY


 (1) – Off	 (13) – Cancel	 (19) – “Off”
 (2) – On	 (14) – Accept	 (20) – “On”
 (7) – Light Off	 (15) –Door Open	 (21) – Unsecure
 (8) – Light On	 (16) –Door Closed	 (22) – Secure
 (9) – Light Off 2	 (17) –Window Open	
 (10) – Light On 2	 (18) –Window Closed	

#### DIRECTIONAL & INCREMENTAL

 (33) – Down Shutter	 (35) – Down Shutter 2
 (34) – Up Shutter	 (36) – Up Shutter 2

#### AIR CONDITIONING

 (45) – Off A/C	 (56) –Highest Fan
 (46) – On A/C	 (57) – Stop (no swing)
 (47) – Cool Mode	 (58) – Swing
 (48) – Heat Mode	 (59) – Stop
 (49) – Automatic Mode	 (60) – Swing 2


 (50) – Fan Mode

 (51) – Dry Mode

 (52) – Lowest Fan

 (53) – Low Fan

 (54) – Middle Fan

 (55) – High Fan

 (61) – Automatic

 (62) – Automatic 2

 (63) – Automatic 3

 (64) – Automatic 4

## NUMBERS

**0** (66) – Zero

**1** (67) – One

**2** (68) – Two

**3** (69) – Three

**4** (70) – Four

**0** (76) – 0

**5** (71) – Five

**6** (72) – Six

**7** (73) – Seven

**8** (74) – Eight

**9** (75) – Nine

**1** (77) – 1

## SOUND & IMAGE













 (89) – Volume Off

 (90) – Volume On



## OTHER

---

 (96) – Timer 1	 (103) – Ok	 (110) –Cool Warning
 (97) – Timer 2	 (104) – Comfort	 (111) – Heat Warning
 (98) – Timer Off	 (105) – Economy	 (112) –Wind Warning
 (99) – Timer On	 (106) – Standby	 (113) – Key 1
 (100) – Make Up Room	 (107) – Strong	 (114) – Key 2
 (101) – Do Not Disturb	 (108) – Very Strong	 (115) – New
 (102) – Set	 (109) – Warning	



**BECOME USER!**

<http://zennioenglish.zendesk.com>

**TECHNICAL SUPPORT**